

PHOSPHATE YELLOW COLORIMETRIC ANALYZER

Compact online analyzer for measurement of phosphate in water

APPLICATION FIELDS

- Power Utility
- Cooling water
- · Drinking water
- Boiler feedwater
- Industrial and municipal wastewater
- Surface water



ADVANTAGES / FEATURES

• Different compartments

To ensure complete separation between the electronics (upper case) and the wet part (lower case).

• One reagent configuration, low reagent consumption

Minimum operating cost by small reagent consumption, only 2.5 L (0.66 US.gal) for the 16 mm cell / 5 L (1.32 US.gal) for the 26 mm cell of each reagent every 90 days with 15 minute analysis frequency.

• Automatic calibration / validation / cleaning

Validation, cleaning and calibration are standard features which significantly reduce downtime and operator intervention ensuring the most accurate results are obtained. Free selectable validation, cleaning and calibration intervals.

• Wide measuring range

The determination ranges of the Phosphate Analyzer vary from trace $\mu g/L$ to 2000 mg/L PO $_4$ using internal dilution module.

• Large color touchscreen

The colorimeter is equipped with a graphic touchscreen interface showing measured values and status information. Easy access to menus and functions. Integrated datalogger with USB download.

Factory tested, ready for installation and operation

Just connect the power, sample, and reagent lines and the analyzer is fully operational.


• Measurement principle

The reagent, containing sodium molybdate and ammonium meta-vanadate in an acid medium, reacts with the orthophosphate to form a yellow coloured phosphovanado-molybdate compound. The absorbance intensity is proportional to the phosphate concentration in the sample and is determined at 430 nm.

TECHNICAL SPECIFICATIONS

Measured parameter	PO ₄ / P-PO ₄ (ppb, ppm, mg/l). Phosphates / reactive phosphorus
Measuring	Differential colorimetric absorbance.
principle	Yellow method.
Measuring range	0.05 to 10 ppm P-PO $_4$ (30 ppm PO $_4$) for the 26 mm cell 0.1 to 16 ppm P-PO $_4$ (50 ppm PO $_4$) for the 16 mm cell Up to 640 ppm P-PO $_4$ (2000 ppm PO $_4$) with internal dilution.
Reproducibility	\pm 200 ppb or \pm 5%, whichever is greater (26 mm cell) \pm 500 ppb or \pm 5%, whichever is greater (16 mm cell).
Analysis Frequency	Freely programmable, batch near-continuous analysis.
Cycle time	8-10 minutes, including conditioning before analysis cycle and rinsing after measuring.
Reaction cell	Temperature heated
Sample	Pressure-free vessel Temperature: 5 - 50 °C (41 - 122 °F) Flow Rate: 80 to 500 mL/min Connection: 6 mm (¼-in.)
Drain	Pressure-free, atmospheric drain Connection: 12 mm (½-in.)
N° of streams	1, 2 with integrated switching valve
Dimensions (H x W x D)	604 x 380 x 242 mm (23.6 x 14.8 x 9.4 in)
Weight	Approx. 20 Kg (44 lbs)
Power Supply	Voltage: 100 - 240 VAC 50/60 Hz standard or 24 VDC (option) Power consumption: max. 80 VA
Outputs	2 x 4-20 mA outputs for measured data Modbus RTU RS485
Alarms	2 SPDT programmable potential free relays
Digital Input	Remote start/stop, start extra cycle, skip idle time, emergency stop
Working Temperature	5 - 45 °C (41 - 113 °F)
Humidity	10 to 90% RH (indoor use only)
Installation	Wall mount (standard), bench top support or panel mount (options).
Protection Grade	IP54

INSTALLATION EXAMPLE



The analyzer is easily installed in a minimum amount of wall space.


In the picture are included the optional accessories:

- a) A46ERLS000 Fast Loop external reservoir with level switch
- b) A46SF10020 Filtration unit 100 micron 230 VAC (other mesh size and input voltages available)
- c) A46SPP0000 Sampling Pump


Other accessories, including external dilutors to increase the analyzer range and different kind of sample reservoirs are also available. See our website for more info.



TECHNICAL DRAWING



HYDRAULIC COMPARTMENT VIEW



PRODUCT CODES

CL3-1-430-0-16-PO4	Colorimeter Phosphate Yellow, one inlet port, 16 mm cell
CL3-1-430-2-16-PO4	Colorimeter Phosphate Yellow, two inlet ports, 16 mm cell
CL3-1-430-3-16-PO4	Colorimeter Phosphate Yellow, three inlet ports, 16 mm cell
CL3-1-430-0-26-PO4	Colorimeter Phosphate Yellow, one inlet port, 26 mm cell
CL3-1-430-2-26-PO4	Colorimeter Phosphate Yellow, two inlet porst, 26 mm cell
CL3-1-430-3-26-PO4	Colorimeter Phosphate Yellow, three inlet port, 26 mm cell