



SAMPLE COOLER SC-1



DESCRIPTION

The cooler consists of a stainless steel coil, through which the sample flows, and a stainless steel body, through which cooling water flows in the opposite direction.

FEATURES

- Compact design with double helicoidal coil
- Very close approach temperatures in sample with the cooling water entry.
- Coil in one piece to ensure low maintenance (no joints).
- Easy maintenance: Coils can be cleaned in-place.
- Others material, please consult.

SPECIFICATIONS

Model:	SC-1-B-10-K	SC-1-B-10-L
Colling area:	0,11 m² (1,2 ft²)	
Tube material / size:	316SS 1/4	"OD x 0,049"
Tube rating:	245bar(g)[3553 psi(g)] @ 540°C (1004 °F)
Shell material	304 SS	316 SS
Shell rating:	30 bar (435 ps	i) @ 200°C (392°F)
Weight:	51	(g (11lb)
Optimal flow service:		
Single fase:	100	0 cc/min
Condensing heat transfer:	700	cc/min

^{*}All coolers are supplied with bracket in SS304

^{*}These references correspond to standard references, usually in stock. For other combinations, please consult.








CONNECTIONS

Name	Size & Type
Sample Inlet	1/4" OD Tube
Sample Outlet	1/4" OD Tube
Cooling water inlet	3/4" NPT(f)
Cooling water outlet	1/2" NPT(f)

SPARE PARTS

Name	Part#
Cover "O" ring for SC-1 / SC-2	CL20

DIMENSIONS



Units: mm [Inches in brackets]

Due to continuous improvements, Manvia reserves the right to change the design and specifications without notice